



## CT-6B Classic Blade Trim With Ivy

### Tools Required

Permanent Marker  
Drill Template (Included)  
Hammer  
Center Punch  
3/8" Drill Bit  
3/4" Wrench

### Hardware Required

(2) 5/16-18 stainless hex-bolts  
Classic Blade Trim With Ivy

### Marking and Drilling Post

- 1) Locate sign height on installed post.
- 2) Use the included drill template to mark drill locations for 2 mounting holes.
- 3) Mark the opposite side of post at the same height (it is recommended to drill each side of post separately to ensure the holes line up properly through the fluted post).
- 4) Center punch each of 4 hole locations.
- 5) Drill 4 holes, 2 on each side of post, creating 2 through holes with a 3/8" drill bit.
- 6) Attach Classic Blade Trim to post using (2) 5/16-18 hex bolts.
- 7) Tighten bolts until trim is snug to post.
- 8) Repeat this process when installing a 2nd blade trims to the same post. Remember that the second sign must be located at a different height so that the bolts do not interfere with each other.